

KNEES FREE FLUID FILLER

Designed to keep you off your knees!

FLUID FILLER USAGE INSTRUCTIONS

1. Slide bottle into the metal basket at the bottom of the FLUIDFILLER until it clicks in place. It may take some effort as the fit is tight. Remove the cap.
2. Lower the FLUIDFILLER into the water to be tested about 1.5 feet down, holding just the main handle. *(Chlorine at the surface of the water has been broken down by the sun and will not reveal accurate water chemistry)*
3. Lift the inner handle up with one finger until bubbles come out as the water will flow into the bottle. It takes 7-8 seconds to fully fill the bottle. If you are only going to fill a test kit, allow the bottle to fill for 3 seconds.
4. To retract from pool, release the inner handle, lift up the tool by the main handle and remove from pool.
5. Place the cap on bottle and remove the bottle by pulling up and away from the FLUIDFILLER. *(Again this will take a little effort)*

FLUIDFILLER STORAGE INSTRUCTIONS

1. Remove the bottle and keep it indoors between testing. Hang the FLUID FILLER on a nail or hook in a shaded area away from direct sunlight.

The FLUID FILLER is designed to give you years and years of faithful service. Keeping it out of direct sunlight and storing the plastic bottle indoors between testing will keep the FLUID FILLER functioning great.

DO NOT USE A GLASS BOTTLE